Pinpoint System User Guide

PINPOINT®

ACTIVATE → ALERT → RESPOND → RESET









Activating an Alarm

EMERGENCY

EMERGENCY

Activate: Pull the retaining pin from PIT, press large button on reverse of Badge PIT or push emergency Call Button.

Identify: **Red** on display, continuous sound.

ASSISTANCE

ASSISTANCE

Activate: Press the button located at the bottom of the PIT, press the small button on the top left on reverse of Badge PIT or push assistance Call Button.

Identify: **Green** on display, intermittent sound.

CALL

PATIENT CALL

Activate: Press Patient Call Button unit.


Identify: **Orange** on display, intermittent sound.

Before Starting Your Shift

and after Emergency activation



Energize Perpetual PIT



Test your PIT

Training Guides

Scan the QR code for video guides.

Perpetual and Battery PITs feature a battery level status LED, which shines through the top of the unit. Battery status on Badge PIT is checked by pressing button on reverse. A green LED will indicate sufficient battery or a red LED indicate batteries need replaced.

Pinpoint System User Guide

How the System Works

Using Personal Infrared Transmitters (PITs), staff can activate Assistance and Emergency alarm calls. When activated, infrared signals are transmitted to receiver units located in the building's ceiling which send the alert on to communication devices and displays. These then provide the exact location and level of the activated alarm.

Activate - Activate the System by triggering an alarm with your PIT or Call Button.

Alert - Identify where the alarm/incident is taking place using visual and audio identifiers from Display Units, Overdoor Lights and Sounders.

Respond - Respond to the alarm appropriately as per on-site procedure.

Reset - Reset the alarm once the incident has been responded to using a Reset Hub and appropriate reset fob, to reset a range of units, or local unit reset, to reset a single unit.

Activate



Pull retaining pin for Emergency or push button at bottom of PIT for Assistance call.

PITs



Push large button on reverse of PIT to activate Emergency alarm, or press small button for Assistance call.

Badge PIT



Push appropriate call button for either Emergency, Assistance or Patient call .

Call Button

Alert



Display Units provide colour coded displays of location and call level.

Display Units



Overdoor lights provide a colour coded indicator at the location of alarm.

Total Overdoor Lights



Sounders provide an audible tone for the appropriate level of call.

Sounder

Reset



Present appropriate reset fob to window on the Reset Hub or Call Button.

Reset Hub



Present mute fob to mute all units within that range. LEDs will illuminate red when muted.

Mute Unit



Present Arm/Disarm fob to either Arm or Disarm the unit.

Arm/Disarm