



PINPOINT LTD

Protecting People at Work.....



PATIENT CALL PUSH BUTTON WITH RESET

**Backbox:** 2 gang 35mm deep (MK886ZIC)

**Model No.** 132

The 'Patient Call' Push Button is 2 gang in size, manufactured from ABS, incorporating Biomaster anti-microbial technology. It is installed HORIZONTALLY at a convenient height for patients/residents to activate.

Normal location is in Accessible WCs, WCs, common rooms etc.

Reset is via a Reset Switch on the fascia of the Button and the disarm function is available as shown **if required**.

When the orange button is pressed, the red LED on the fascia of the Push Button flashes to indicate successful activation, the exact room location of activation is displayed on all relevant Alphanumeric Display Units as well as the type of call 'P' or 'PATIENT CALL' and if connected to an Over Door Light (ODL) this will also flash above the entrance to the room. The colour of the LED that flashes in the ODL can be red, green, orange, yellow, blue or purple.